

## **Stone Computers**

# Driver Packs and Resources for CC4

v1.44 13<sup>th</sup> May 2014 Andrew Sharrad



## **Contents**

General Information	3
D 11111 .	
Build Notes	4
Recommended BIOS Settings	5
necommended blog settings	3
Which INF files to Import?	5
Desktops	
Intel DH61DL / Intel DH67BL	6
Ctore (MCI) IICAM D24/C2) / IICAM D24/M0	7
Stone (MSI) H61M-P31(G3) / H61M-P31/W8	7
Stone (MSI) H61I-E35 (Mini-ITX)	8
3.6.1.e (1.1.3.) 11.0.1. 12.3.s (1.11.11.11.17.)	G
Intel DH61AG / Intel DH61CR / Intel DH61WW	9
Asus P8B75-M	10
Desktops – 2014 Model Range	
Stone (MSI) H81M-P33	11
Stone (Asus) H81T	12
Stolle (Asus) Hoti	12
Stone (Asus) B85M-E	13
Stone (Asus) Q87-T / Stone (Asus) CS-B	14
Notebooks, Netbooks and Tablets	
Stone NT309 Notebook	15
C. NEGGO N	4-
Stone NT310 Notebook	17
* New for 2014 * Stone NT310-H Notebook	19
New 101 2014 Stolle N1310-11 Notebook	19
Stone Classmate 2 (N109RV)	21
,	
N120 Netbook	22
Intel 7260 Wireless Adapter	24
Other	25
AMD / ATI Radeon Graphics	25
Getting Further Support	26
Getting ruither Support	40

## **General Information**

Thank you for your interest in Stone Computers.

We can supply a range of resources and services to help you deploy your Stone Computers notebook or desktop PC systems in your CC4 environment.

This document details some of the available downloads for customers wishing to add driver support to their CC4 build console.

If you need additional support, or are interesting in our range of deployment solutions (including installation to desk, PC imaging, network migrations and virtualised infrastructures) then please contact your account manager.

If you are looking for CC3 support then please contact your account manager or Stone Support for a copy of our Stone Driver Deployment Utility (DDU) software.

Kind Regards,

Stone Support.

## **Build Notes**

#### Pre-Build Process – the Build CD or Image

- Always use the most up to date driver available.
- Always remove previous drivers for the same device driver or family of drivers. For example, to support the latest Realtek Gigabit PCI-E network cards, add the latest driver after first removing the previous version of the driver.
- Add the correct driver bearing in mind which operating system you plan to deploy:
  - Windows 7 x86 this needs a Windows Vista 32bit PE driver
  - O Windows 7 x64 this needs a Windows 7 x86/32bit PE driver
- Don't forget to remake the build image after updating the drivers.

#### **Target Operating System Drivers**

- Always install the latest hardware support packs first. Then try building your Stone system and see if further driver support is needed
  - For example, if the system builds but there are "Unknown" device in Device Manager, then you will need to add the driver packs.
- For all of your Stone drivers, use this document to see which models share the same driver packs. For example, if you have a mixture of the "DH61AG/DH61CR/DH61WW" and the "DH61DL/DH67BL" family, use the DH61DL/DH67BL packs as these support all models.
- Use your regular instructions to add drivers to the console as you would for any third party system.
- You may need to remove older version of the same driver, especially graphics card and network card drivers.
- Some systems may have packages that cannot be deployed using the CC4 console. For example, notebook Hotkey applications. Downloads for the regular installers for this software are always provided.
- Contact Stone support if you need further assistance.

## **Recommended BIOS Settings**

The BIOS settings available across models vary however some of the common recommended settings for Windows 7 deployments are listed below.

SATA Controller Configuration AHCI Mode > Enabled	It is recommended to have AHCI turned on (as opposed to IDE mode) as this gives the best performance, especially with SSD based systems.
Boot Options Secure Boot > Disabled  or Advanced Options Windows 8 Configuration > Secure Boot > Disabled	Secure boot is an option for Windows 8. This needs to be disabled for Windows 7 based systems.
Boot Options UEFI Mode > <b>Disabled</b>	UEFI mode is an option mainly for Windows 8 systems or systems with very large hard drives. It is recommended that UEFI is disabled for Windows 7.
Advanced Options Windows 8 Features > <b>Disabled</b>	Some BIOSes have one overall setting for Windows 8 – Windows 8 Features. We recommend that these are disabled for Windows 7.

## Which INF files to Import?

Most driver packages now include a small text file which tells you exactly which driver files you need to import into your build console. When about to import drivers, we recommend you print the list and work through it. Whilst most lists are quite short, it is important not to miss a driver, to ensure that you have no "Unknown Devices" in Device Manager at the end of the build process.

## Intel DH61DL / DH67BL Drivers for CC4

This model is very similar to the DH61AG/DH61CR/DH61WW except that the DH61DL/DH67BL has a USB3 controller. Use this package if you have both groups of models.

#### Windows 7 x86

Driver required for Pre-Build Process: Windows Vista / PE:

Intel LAN -

http://www.stonecomputers.com/ftp/andrews/dh61dl dh67bl/vista/Pro1000 WinVista 32-17.4.zip

Alternative LAN Driver: <a href="http://www.stonecomputers.com/ftp/andrews/pro1000">http://www.stonecomputers.com/ftp/andrews/pro1000</a> vista32 15.7.zip
This driver is required for the build CD or build image.

When the Vista driver above is added, you must specify that this is for Windows Vista and Windows PE (versions 2.0, 2.1 and 2.2). Do not select Windows 7 or Windows PE 3.0 or 3.1.

#### **Drivers required for Target Operating System (Post-Installation):**

http://www.stonecomputers.com/ftp/andrews/dh61dl dh67bl/cc4/x86pack/dh61dl dh67bl.zip Please extract this ZIP file to a folder, and then add each driver to your build console. Please select Windows 7 (All Versions) only.

Contents: Realtek Audio, HDMI, Intel PRO1000 LAN, MEI (Management Engine), Renesas USB3.0, and Intel VGA Drivers

#### Windows 7 x64

Driver required for Pre-Build Process: Windows 7-32bit / PE:

http://www.stonecomputers.com/ftp/andrews/dh61dl dh67bl/Win7x86/Pro1000 Win7 32-17.4.zip

This driver is required for the build CD or build image.

When the Windows 7 32-bit driver above is added, you must specify that this is for Windows 7 32bit and Windows PE (versions 3.0 and 3.1). Do not select Windows Vista or Windows PE 2.x.

#### **Drivers required for Target Operating System (Post-Installation):**

http://www.stonecomputers.com/ftp/andrews/dh61dl dh67bl/cc4/x64pack/dh61dl dh67blx64.zi

Please extract this ZIP file to a folder, and then add each driver to your build console. Please select Windows 7 (All Versions) only.

Contents: Realtek Audio, HDMI, Intel PRO1000 LAN, MEI (Management Engine), Renesas USB3.0, and Intel VGA Drivers

## Stone (MSI) H61M-P31(G3) / H61M-P31/W8 Drivers for CC4

Factory BIOS for the H61M-P31/W8 model only (to be used on machines which had a downgrade installed to support CC3):

http://www.stonecomputers.com/ftp/andrews/h61m-p31-w8/h61m-p31-w8-322-dos-win.zip This package contains both Windows98SE (DOS) and Windows runtime updaters.

#### Windows 7 x86

Driver required for Pre-Build Process: Windows Vista / PE:

http://www.stonecomputers.com/ftp/andrews/h61m-p31-w8/vista/RTL LAN Vista x86.zip This driver is required for the build CD or build image.

When the Vista driver above is added, you must specify that this is for Windows Vista and Windows PE (versions 2.0, 2.1 and 2.2). Do not select Windows 7 or Windows PE 3.0 or 3.1.

#### **Drivers required for Target Operating System (Post-Installation):**

http://www.stonecomputers.com/ftp/andrews/h61m-p31-w8/cc4/x86pack/h61m-p31-w8-cc4.zip Please extract this ZIP file to a folder, and then all of the drivers to your build console. Please select Windows 7 (All Versions) only.

Contents: Audio, HDMI, LAN, MEI (Management Engine), and VGA Drivers

#### Windows 7 x64

Driver required for Pre-Build Process: Windows 7-32bit / PE:

http://www.stonecomputers.com/ftp/andrews/h61m-p31-w8/win7/RTL LAN Win7 x86.zip This driver is required for the build CD or build image.

When the Windows 7 32-bit driver above is added, you must specify that this is for Windows 7 32bit and Windows PE (versions 3.0 and 3.1). Do not select Windows Vista or Windows PE 2.x.

#### **Drivers required for Target Operating System (Post-Installation):**

http://www.stonecomputers.com/ftp/andrews/h61m-p31-w8/cc4/x64pack/h61m-p31-w8-cc4x64.zip

Please extract this ZIP file to a folder, and then all of the drivers to your build console. Please select Windows 7 (All Versions) only.

Contents: Audio, HDMI, LAN, MEI (Management Engine), and VGA Drivers

## Stone (MSI) H61I-E35 (Mini-ITX) Drivers for CC4

As of 11/14/2014, these drivers are identical to the H61M-P31(G3) and H61M-P31/W8. Contact Stone Support for further updates.

#### Windows 7 x86

#### Driver required for Pre-Build Process: Windows Vista / PE:

http://www.stonecomputers.com/ftp/andrews/h61i-e35/vista/RTL LAN Vista x86.zip This driver is required for the build CD or build image.

When the Vista driver above is added, you must specify that this is for Windows Vista and Windows PE (versions 2.0, 2.1 and 2.2). Do not select Windows 7 or Windows PE 3.0 or 3.1.

#### **Drivers required for Target Operating System (Post-Installation):**

http://www.stonecomputers.com/ftp/andrews/h61i-e35/cc4/x86pack/h61i-e35-cc4.zip
Please extract this ZIP file to a folder, and then all of the drivers to your build console. Please select Windows 7 (All Versions) only.

Contents: Audio, HDMI, LAN, MEI (Management Engine), and VGA Drivers

#### Windows 7 x64

#### Driver required for Pre-Build Process: Windows 7-32bit / PE:

http://www.stonecomputers.com/ftp/andrews/h61i-e35/win7/RTL LAN Win7 x86.zip

This driver is required for the build CD or build image.

When the Windows 7 32-bit driver above is added, you must specify that this is for Windows 7 32bit and Windows PE (versions 3.0 and 3.1). Do not select Windows Vista or Windows PE 2.x.

#### **Drivers required for Target Operating System (Post-Installation):**

http://www.stonecomputers.com/ftp/andrews/h61i-e35/cc4/x64pack/h61i-e35-cc4x64.zip Please extract this ZIP file to a folder, and then all of the drivers to your build console. Please select Windows 7 (All Versions) only.

Contents: Audio, HDMI, LAN, MEI (Management Engine), and VGA Drivers

## Intel DH61AG / DH61CR / DH61WW Drivers for CC4

These models are very similar to the DH61DL/DH67BL except that they do not have the USB3 controller. If you have both groups of model, use the DH61DL/DH67BL packs.

#### Windows 7 x86

#### Driver required for Pre-Build Process: Windows Vista / PE:

http://www.stonecomputers.com/ftp/andrews/dh61cr/vista/Pro1000 WinVista 32-17.4.zip
Alternative LAN Driver: http://www.stonecomputers.com/ftp/andrews/pro1000 vista32 15.7.zip
INF that needs to be imported: e1c6032.inf

This driver is required for the build CD or build image.

When the Vista driver above is added, you must specify that this is for Windows Vista and Windows PE (versions 2.0, 2.1 and 2.2). Do not select Windows 7 or Windows PE 3.0 or 3.1.

#### **Drivers required for Target Operating System (Post-Installation):**

http://www.stonecomputers.com/ftp/andrews/dh61cr/cc4/x86pack/DH61CR WW.zip

Please extract this ZIP file to a folder, and then add all of the drivers to your build console. Please select Windows 7 (All Versions) only.

Contents: Realtek Audio, HDMI, LAN, MEI (Management Engine) and Intel VGA Drivers

#### Windows 7 x64

#### Driver required for Pre-Build Process: Windows 7-32bit / PE:

http://www.stonecomputers.com/ftp/andrews/dh61cr/Win7x86/Pro1000 Win7 32-17.4.zip This driver is required for the build CD or build image.

When the Windows 7 32-bit driver above is added, you must specify that this is for Windows 7 32bit and Windows PE (versions 3.0 and 3.1). Do not select Windows Vista or Windows PE 2.x.

#### **Drivers required for Target Operating System (Post-Installation):**

http://www.stonecomputers.com/ftp/andrews/dh61cr/cc4/x64pack/DH61CR WWx64.zip Please extract this ZIP file to a folder, and then add all of the drivers to your build console. Please select Windows 7 (All Versions) only.

Contents: Realtek Audio, HDMI, LAN, MEI (Management Engine) and Intel VGA Drivers

## Asus P8B75-M Drivers for CC4

#### Windows 7 x86

Driver required for Pre-Build Process: Windows Vista / PE:

http://www.stonecomputers.com/ftp/andrews/p8b75-m/vista/RTL LAN Vista x86.zip This driver is required for the build CD or build image.

When the Vista driver above is added, you must specify that this is for Windows Vista and Windows PE (versions 2.0, 2.1 and 2.2). Do not select Windows 7 or Windows PE 3.0 or 3.1.

#### **Drivers required for Target Operating System (Post-Installation):**

http://www.stonecomputers.com/ftp/andrews/p8b75-m/cc4/x86pack/p8b75-m-cc4.zip Please extract this ZIP file to a folder, and then all of the drivers to your build console. Please select Windows 7 (All Versions) only.

Contents: Audio, HDMI, LAN, MEI (Management Engine), USB3, PANT SMB Chipset and VGA Drivers

#### Windows 7 x64

Driver required for Pre-Build Process: Windows 7-32bit / PE:

http://www.stonecomputers.com/ftp/andrews/p8b75-m/win7/RTL LAN Win7 x86.zip This driver is required for the build CD or build image.

When the Windows 7 32-bit driver above is added, you must specify that this is for Windows 7 32bit and Windows PE (versions 3.0 and 3.1). Do not select Windows Vista or Windows PE 2.x.

#### **Drivers required for Target Operating System (Post-Installation):**

http://www.stonecomputers.com/ftp/andrews/p8b75-m/cc4/x64pack/p8b75-m-cc4x64.zip Please extract this ZIP file to a folder, and then all of the drivers to your build console. Please select Windows 7 (All Versions) only.

Contents: Audio, HDMI, LAN, MEI (Management Engine), USB3, PANT SMB Chipset and VGA Drivers

## Stone (MSI) H81M-P33 Drivers for CC4

#### Windows 7 x86

Driver required for Pre-Build Process: Windows Vista / PE:

http://www.stonecomputers.com/ftp/andrews/h81m-p33/vista/RTL LAN Vista x86.zip This driver is required for the build CD or build image.

When the Vista driver above is added, you must specify that this is for Windows Vista and Windows PE (versions 2.0, 2.1 and 2.2). Do not select Windows 7 or Windows PE 3.0 or 3.1.

#### **Drivers required for Target Operating System (Post-Installation):**

http://www.stonecomputers.com/ftp/andrews/h81m-p33/cc4/x86pack/h81m-p33-cc4.zip Please extract this ZIP file to a folder, and then all of the drivers to your build console. Please select Windows 7 (All Versions) only.

Contents: Audio, HDMI, LAN, MEI (Management Engine), USB3, SMB Chipset and VGA Drivers

#### Windows 7 x64

Driver required for Pre-Build Process: Windows 7-32bit / PE:

http://www.stonecomputers.com/ftp/andrews/h81m-p33/win7/RTL LAN Win7 x86.zip This driver is required for the build CD or build image.

When the Windows 7 32-bit driver above is added, you must specify that this is for Windows 7 32bit and Windows PE (versions 3.0 and 3.1). Do not select Windows Vista or Windows PE 2.x.

#### **Drivers required for Target Operating System (Post-Installation):**

http://www.stonecomputers.com/ftp/andrews/h81m-p33/cc4/x64pack/h81m-p33-cc4x64.zip Please extract this ZIP file to a folder, and then all of the drivers to your build console. Please select Windows 7 (All Versions) only.

Contents: Audio, HDMI, LAN, MEI (Management Engine), USB3, SMB Chipset and VGA Drivers

## Stone (Asus) H81T Drivers for CC4

#### Windows 7 x86

Driver required for Pre-Build Process: Windows Vista / PE:

http://www.stonecomputers.com/ftp/andrews/h81t/vista/RTL LAN Vista x86.zip

This driver is required for the build CD or build image.

When the Vista driver above is added, you must specify that this is for Windows Vista and Windows PE (versions 2.0, 2.1 and 2.2). Do not select Windows 7 or Windows PE 3.0 or 3.1.

#### **Drivers required for Target Operating System (Post-Installation):**

http://www.stonecomputers.com/ftp/andrews/h81t/cc4/x86pack/h81t-cc4.zip

Please extract this ZIP file to a folder, and then all of the drivers to your build console. Please select Windows 7 (All Versions) only.

Contents: ACPI, ASMedia USB 3, Audio, HDMI, LAN, MEI (Management Engine), Intel USB3, SMB Chipset and VGA Drivers

#### Windows 7 x64

Driver required for Pre-Build Process: Windows 7-32bit / PE:

http://www.stonecomputers.com/ftp/andrews/h81t/win7/RTL LAN Win7 x86.zip

This driver is required for the build CD or build image.

When the Windows 7 32-bit driver above is added, you must specify that this is for Windows 7 32bit and Windows PE (versions 3.0 and 3.1). Do not select Windows Vista or Windows PE 2.x.

#### **Drivers required for Target Operating System (Post-Installation):**

http://www.stonecomputers.com/ftp/andrews/h81t/cc4/x64pack/h81t-cc4x64.zip

Please extract this ZIP file to a folder, and then all of the drivers to your build console. Please select Windows 7 (All Versions) only.

Contents: ACPI, ASMedia USB 3, Audio, HDMI, LAN, MEI (Management Engine), Intel USB3, SMB Chipset and VGA Drivers

## Stone (Asus) B85M-E Drivers for CC4

This motherboard uses similar drivers as for the P8B75-M however the USB3 and Audio drivers are different.

#### Windows 7 x86

#### Driver required for Pre-Build Process: Windows Vista / PE:

http://www.stonecomputers.com/ftp/andrews/b85m-e/vista/RTL LAN Vista x86.zip This driver is required for the build CD or build image.

When the Vista driver above is added, you must specify that this is for Windows Vista and Windows PE (versions 2.0, 2.1 and 2.2). Do not select Windows 7 or Windows PE 3.0 or 3.1.

#### **Drivers required for Target Operating System (Post-Installation):**

http://www.stonecomputers.com/ftp/andrews/b85m-e/cc4/x86pack/b85m-e-cc4.zip

Please extract this ZIP file to a folder, and then all of the drivers to your build console. Please select Windows 7 (All Versions) only.

Contents: ACPI, Audio, HDMI, LAN, MEI (Management Engine), USB3, SMBus Chipset and VGA Drivers

#### Windows 7 x64

#### Driver required for Pre-Build Process: Windows 7-32bit / PE:

http://www.stonecomputers.com/ftp/andrews/b85m-e/win7/RTL LAN Win7 x86.zip This driver is required for the build CD or build image.

When the Windows 7 32-bit driver above is added, you must specify that this is for Windows 7 32bit and Windows PE (versions 3.0 and 3.1). Do not select Windows Vista or Windows PE 2.x.

#### **Drivers required for Target Operating System (Post-Installation):**

http://www.stonecomputers.com/ftp/andrews/b85m-e/cc4/x64pack/b85m-e-cc4x64.zip Please extract this ZIP file to a folder, and then all of the drivers to your build console. Please select Windows 7 (All Versions) only.

Contents: ACPI, Audio, HDMI, LAN, MEI (Management Engine), USB3, SMBus Chipset and VGA Drivers

## Stone (Asus) Q87-T / Stone (Asus) CS-B Drivers for CC4

These motherboards are based upon the Intel Q87 chipset. Its standard LAN controller is based upon an Intel model that does not have support for Windows Vista. This means that the system cannot support the Windows 7 32bit (x86) CC4 build process, as this relies upon Windows Vista PE.

This motherboard only supports the Windows 7 x64 build process as LAN drivers are available for the build stage, which relies upon Windows 7 32bit (x86).

#### Windows 7 x86

Not supported

#### Windows 7 x64

Driver required for Pre-Build Process: Windows 7-32bit / PE:

http://www.stonecomputers.com/ftp/andrews/cs-b/win7/INTEL LAN Win7 x86.zip

This driver is required for the build CD or build image.

When the Windows 7 32-bit driver above is added, you must specify that this is for Windows 7 32bit and Windows PE (versions 3.0 and 3.1). Do not select Windows Vista or Windows PE 2.x.

#### **Drivers required for Target Operating System (Post-Installation):**

http://www.stonecomputers.com/ftp/andrews/cs-b/cc4/x64pack/cs-b-cc4x64.zip

Please extract this ZIP file to a folder, and then all of the drivers to your build console. Please select Windows 7 (All Versions) only.

Contents: ACPI, Audio, HDMI, LAN, MEI (Management Engine), USB3, SMBus Chipset and VGA Drivers

## **Stone NT309 Drivers for CC4**

#### Windows 7 x86

Driver required for Pre-Build Process: Windows Vista / PE:

http://www.stonecomputers.com/ftp/andrews/nt309/vista/RTL LAN Vista x86.zip

This driver is required for the build CD or build image.

When the Vista driver above is added, you must specify that this is for Windows Vista and Windows PE (versions 2.0, 2.1 and 2.2). Do not select Windows 7 or Windows PE 3.0 or 3.1.

#### **Drivers required for Target Operating System (Post-Installation):**

http://www.stonecomputers.com/ftp/andrews/nt309/cc4/x86pack/nt309.zip

Please extract this ZIP file to a folder, and then add this entire folder to your build console. Please select Windows 7 (All Versions) only.

Contents: Audio, Card Reader, HDMI, LAN, MEI (Management Engine), USB3.0, VGA and Intel WLAN Drivers

#### **Optional Applications for Windows 7 x86:**

**Hotkey Utility** 

http://www.stonecomputers.com/ftp/andrews/nt309/win7/common/Hotkey.zip

#### Intel Bluetooth Software

http://www.stonecomputers.com/ftp/andrews/nt309/allos/Intel bluetooth BT 3.1.1309 s32.exe

#### Camera Driver

http://www.stonecomputers.com/ftp/andrews/nt309/allos/chiconycam.zip

#### **Touchpad Software**

http://www.stonecomputers.com/ftp/andrews/nt309/allos/Synaptics v15 2 20 C XP32 Vista32 Win7-32 Signed Marketing SGS94 UI-Scrybe.exe

#### **Stone NT309 Drivers for CC4 continued**

#### Windows 7 x64

Driver required for Pre-Build Process: Windows 7-32bit / PE:

http://www.stonecomputers.com/ftp/andrews/nt309/win7/RTL LAN Win7 x86.zip

This driver is required for the build CD or build image.

When the Windows 7 32-bit driver above is added, you must specify that this is for Windows 7 32bit and Windows PE (versions 3.0 and 3.1). Do not select Windows Vista or Windows PE 2.x.

#### **Drivers required for Target Operating System (Post-Installation):**

http://www.stonecomputers.com/ftp/andrews/nt309/cc4/x64pack/nt309x64.zip

Please extract this ZIP file to a folder, and then add this entire folder to your build console. Please select Windows 7 (All Versions) only.

Contents: Audio, Card Reader, HDMI, LAN, MEI (Management Engine), USB3.0, VGA and Intel WLAN Drivers

#### **Optional Applications for Windows 7 x64:**

**Hotkey Utility** 

http://www.stonecomputers.com/ftp/andrews/nt309/win7/common/Hotkey.zip

#### Intel Bluetooth Software

http://www.stonecomputers.com/ftp/andrews/nt309/allos/Intel bluetooth BT 3.1.1309 s64.exe

#### Camera Driver

http://www.stonecomputers.com/ftp/andrews/nt309/allos/chiconycam.zip

#### **Touchpad Software**

http://www.stonecomputers.com/ftp/andrews/nt309/allos/Synaptics v15 2 20 C XP64 Vista64 Win7-64 Signed Marketing SGS94 UI-Scrybe.exe

### **Stone NT310 Drivers for CC4**

The NT310 Drivers are very similar to the NT309 with the difference of some updated VIA Audio Components, Card Reader Drivers and Hotkey Utility.

The NT310 is available with Intel Sandybridge or Intel Ivybridge Processor graphics. For a package that has an updated Ivybridge video driver, use the Ivybridge NT310 package.

#### Windows 7 x86

Driver required for Pre-Build Process: Windows Vista / PE:

http://www.stonecomputers.com/ftp/andrews/nt310/vista/RTL LAN Vista x86.zip

This driver is required for the build CD or build image.

When the Vista driver above is added, you must specify that this is for Windows Vista and Windows PE (versions 2.0, 2.1 and 2.2). Do not select Windows 7 or Windows PE 3.0 or 3.1.

#### **Drivers required for Target Operating System (Post-Installation):**

**Sandybridge Graphics:** 

http://www.stonecomputers.com/ftp/andrews/nt310/cc4/x86pack/sandynt310.zip lvybridge Graphics (2013 models):

http://www.stonecomputers.com/ftp/andrews/nt310/cc4/x86pack/nt310.zip

Please extract this ZIP file to a folder, and then add this entire folder to your build console. Please select Windows 7 (All Versions) only.

Contents: Audio, Card Reader, HDMI, LAN, MEI (Management Engine), USB3.0, VGA and Intel WLAN Drivers

#### **Optional Applications for Windows 7 x86:**

**Hotkey Utility** 

http://www.stonecomputers.com/ftp/andrews/nt310/win7/common/Hotkey.zip

#### Intel Bluetooth Software

http://www.stonecomputers.com/ftp/andrews/nt310/allos/Intel\_bluetooth\_BT\_17.0.1401.03\_s3\_2.exe

#### Camera Driver

http://www.stonecomputers.com/ftp/andrews/nt310/allos/chiconycam.zip

#### Touchpad Software

http://www.stonecomputers.com/ftp/andrews/nt310/allos/Synaptics v15 2 20 C XP32 Vista32 Win7-32 Signed Marketing SGS94 UI-Scrybe.exe

#### Stone NT310 Drivers Drivers for CC4 continued

#### Windows 7 x64

Driver required for Pre-Build Process: Windows 7-32bit / PE:

http://www.stonecomputers.com/ftp/andrews/nt310/win7/RTL LAN Win7 x86.zip

This driver is required for the build CD or build image.

When the Windows 7 32-bit driver above is added, you must specify that this is for Windows 7 32bit and Windows PE (versions 3.0 and 3.1). Do not select Windows Vista or Windows PE 2.x.

#### **Drivers required for Target Operating System (Post-Installation):**

**Sandybridge Graphics:** 

http://www.stonecomputers.com/ftp/andrews/nt310/cc4/x64pack/sandynt310x64.zip lvybridge Graphics (2013 models):

http://www.stonecomputers.com/ftp/andrews/nt310/cc4/x64pack/nt310x64.zip

Please extract this ZIP file to a folder, and then add this entire folder to your build console. Please select Windows 7 (All Versions) only.

Contents: Audio, Card Reader, HDMI, LAN, MEI (Management Engine), USB3.0, VGA and Intel WLAN Drivers

#### **Optional Applications for Windows 7 x64:**

**Hotkey Utility** 

http://www.stonecomputers.com/ftp/andrews/nt310/win7/common/Hotkey.zip

#### Intel Bluetooth Software

http://www.stonecomputers.com/ftp/andrews/nt310/allos/Intel\_bluetooth\_BT\_17.0.1401.03\_s6\_4.exe\_

#### Camera Driver

http://www.stonecomputers.com/ftp/andrews/nt310/allos/chiconycam.zip

#### **Touchpad Software**

http://www.stonecomputers.com/ftp/andrews/nt310/allos/Synaptics v15 2 20 C XP64 Vista64 Win7-64 Signed Marketing SGS94 UI-Scrybe.exe

### Stone NT310-H Drivers for CC4

The NT310-H is similar to the NT310 however it has an updated chipset and support for Intel "Haswell" processors. There are some other driver differences between the NT310 and NT310-H, most notably the audio controller and card reader.

#### Windows 7 x86

#### Driver required for Pre-Build Process: Windows Vista / PE:

http://www.stonecomputers.com/ftp/andrews/nt310-h/vista/RTL LAN Vista x86.zip

This driver is required for the build CD or build image.

When the Vista driver above is added, you must specify that this is for Windows Vista and Windows PE (versions 2.0, 2.1 and 2.2). Do not select Windows 7 or Windows PE 3.0 or 3.1.

#### **Drivers required for Target Operating System (Post-Installation):**

http://www.stonecomputers.com/ftp/andrews/nt310-h/cc4/x86pack/nt310-h.zip

Please extract this ZIP file to a folder, and then add this entire folder to your build console. Please select Windows 7 (All Versions) only.

Contents: Audio, Card Reader, HDMI, LAN, MEI (Management Engine), USB3.0, VGA and Intel WLAN Drivers

#### **Optional Applications for Windows 7 x86:**

**Hotkey Utility** 

http://www.stonecomputers.com/ftp/andrews/nt310-h/win7/common/Hotkey.zip

#### Intel Bluetooth Software

http://www.stonecomputers.com/ftp/andrews/nt310-

h/win7/common/Intel bluetooth BT 17.0.1401.03 s32.exe

#### Camera Driver

http://www.stonecomputers.com/ftp/andrews/nt310-h/win7/common/camera.zip

#### **Touchpad Software**

http://www.stonecomputers.com/ftp/andrews/nt310-h/win7/common/touchpad.zip

#### Stone NT310-H Drivers Drivers for CC4 continued

#### Windows 7 x64

Driver required for Pre-Build Process: Windows 7-32bit / PE:

http://www.stonecomputers.com/ftp/andrews/nt310-h/win7/RTL LAN Win7 x86.zip

This driver is required for the build CD or build image.

When the Windows 7 32-bit driver above is added, you must specify that this is for Windows 7 32bit and Windows PE (versions 3.0 and 3.1). Do not select Windows Vista or Windows PE 2.x.

#### **Drivers required for Target Operating System (Post-Installation):**

http://www.stonecomputers.com/ftp/andrews/nt310-h/cc4/x64pack/nt310-hx64.zip

Please extract this ZIP file to a folder, and then add this entire folder to your build console. Please select Windows 7 (All Versions) only.

Contents: Audio, Card Reader, HDMI, LAN, MEI (Management Engine), USB3.0, VGA and Intel WLAN Drivers

#### **Optional Applications for Windows 7 x64:**

**Hotkey Utility** 

http://www.stonecomputers.com/ftp/andrews/nt310-h/win7/common/Hotkey.zip

Intel Bluetooth Software <a href="http://www.stonecomputers.com/ftp/andrews/nt310-h/win7/common/Intel-bluetooth-BT-17.0.1401.03">http://www.stonecomputers.com/ftp/andrews/nt310-h/win7/common/Intel-bluetooth-BT-17.0.1401.03</a> s64.exe

#### Camera Driver

http://www.stonecomputers.com/ftp/andrews/nt310-h/win7/common/camera.zip

#### **Touchpad Software**

http://www.stonecomputers.com/ftp/andrews/nt310-h/win7/common/touchpad.zip

## Stone Classmate 2 (N109RV)

This mode is supported by CC4 with the latest Hardware Support Packs installed, as the Classmate 2 shares its drivers with the Minibook.

## **Stone N120 Netbook**

#### Windows 7 x86

Driver required for Pre-Build Process: Windows Vista / PE:

http://www.stonecomputers.com/ftp/andrews/n120/vista/RTL LAN Vista x86.zip

This driver is required for the build CD or build image.

When the Vista driver above is added, you must specify that this is for Windows Vista and Windows PE (versions 2.0, 2.1 and 2.2). Do not select Windows 7 or Windows PE 3.0 or 3.1.

#### **Drivers required for Target Operating System (Post-Installation):**

http://www.stonecomputers.com/ftp/andrews/n120/cc4/x86pack/n120.zip

Please extract this ZIP file to a folder, and then add this entire folder to your build console. Please select Windows 7 (All Versions) only.

This is a new package format. Please let me know if you have any problems importing this package.

Contents: Audio, Card Reader, HDMI, LAN, MEI (Management Engine), VGA, HDMI and Intel WLAN Drivers

#### **Optional Applications for Windows 7 x86:**

**Hotkey Utility** 

http://www.stonecomputers.com/ftp/andrews/nt120/win7/common/N120\_hotkey\_7.zip

#### Intel Bluetooth Software

http://www.stonecomputers.com/ftp/andrews/n120/win7/common/Intel bluetooth BT 17.0.14 01.03 s32.exe

#### Camera Driver

http://www.stonecomputers.com/ftp/andrews/n120/win7/common/Webcam.zip

#### **Touchpad Software**

http://www.stonecomputers.com/ftp/andrews/n120/win7/common/Touchpad.zip

#### Airplane Mode Software

http://www.stonecomputers.com/ftp/andrews/n120/win7/common/Airplane.zip

#### Stone N120 Drivers for CC4 continued

#### Windows 7 x64

Driver required for Pre-Build Process: Windows 7-32bit / PE:

http://www.stonecomputers.com/ftp/andrews/nt120/win7/RTL LAN Win7 x86.zip

This driver is required for the build CD or build image.

When the Windows 7 32-bit driver above is added, you must specify that this is for Windows 7 32bit and Windows PE (versions 3.0 and 3.1). Do not select Windows Vista or Windows PE 2.x.

#### **Drivers required for Target Operating System (Post-Installation):**

http://www.stonecomputers.com/ftp/andrews/n120/cc4/x64pack/n120x64.zip

Please extract this ZIP file to a folder, and then add this entire folder to your build console. Please select Windows 7 (All Versions) only.

This is a new package format. Please let me know if you have any problems importing this package.

Contents: Audio, Card Reader, HDMI, LAN, MEI (Management Engine), VGA, HDMI and Intel WLAN Drivers

#### **Optional Applications for Windows 7 x64:**

**Hotkey Utility** 

http://www.stonecomputers.com/ftp/andrews/nt120/win7/common/Hotkey.zip

#### Intel Bluetooth Software

http://www.stonecomputers.com/ftp/andrews/n120/win7/common/Intel bluetooth BT 17.0.14 01.03 s64.exe

#### Camera Driver

http://www.stonecomputers.com/ftp/andrews/n120/win7/common/Webcam.zip

#### **Touchpad Software**

http://www.stonecomputers.com/ftp/andrews/n120/win7/common/Touchpad.zip

#### Airplane Mode Software

http://www.stonecomputers.com/ftp/andrews/n120/win7/common/Airplane.zip

## **Intel 7260 Wireless Adapter**

The N120 / NT310 / NT310-H packs above do not include support for the Intel 7260 Wireless N or Intel 7260 Wireless AC network adapter. The NT309 is not available with this adapter from the factory.

Please add this alternative wireless driver to your build console if you need to support the Intel 7260 range of wireless Adapters.

#### Windows 7 x86:

#### **Drivers**

http://www.stonecomputers.com/ftp/andrews/intel 7260/Wireless 17.0.0 Ds32.zip

#### Bluetooth Software (cannot be added to build console):

http://www.stonecomputers.com/ftp/andrews/intel\_7260/BT 17.0.1401.03 s32.exe

#### Windows 7 x64:

#### **Drivers**

http://www.stonecomputers.com/ftp/andrews/intel 7260/Wireless 17.0.0 Ds64.zip

#### Bluetooth Software (cannot be added to build console):

http://www.stonecomputers.com/ftp/andrews/intel 7260/BT 17.0.1401.03 s64.exe

#### **Alternative Direct Link:**

https://downloadcenter.intel.com/SearchResult.aspx?lang=eng&ProductFamily=Wireless+Networking&ProductLine=Intel%C2%AE+Wi-

Fi+Products&ProductProduct=Intel%C2%AE+Dual+Band+Wireless-

AC+7260&ProdId=3714&LineId=1784&FamilyId=1783

## **AMD / ATI Radeon Graphics**

If your systems include these graphics adapters then add the drivers below to support them. There is a separate HDMI driver which will need to be installed if you want to use HDMI Audio.

As of 11/11/13, these drivers are based on the Catalyst 13.9 driver package.

#### Windows 7 x86

**Graphics:** 

http://www.stonecomputers.com/ftp/andrews/radeon/radeon\_win7\_x86.zip

**HDMI** Audio:

http://www.stonecomputers.com/ftp/andrews/radeon/radeon hdmi win7 x86.zip

#### Windows 7 x64

Graphics:

http://www.stonecomputers.com/ftp/andrews/radeon/radeon win7 x64.zip

**HDMI** Audio:

http://www.stonecomputers.com/ftp/andrews/radeon/radeon hdmi win7 x64.zip

## **Getting Further Support**

Contact the Stone support team using: 0844 880 2366 or <a href="mailto:support@stonegroup.co.uk">support@stonegroup.co.uk</a>

Alternatively you can raise a support query using our web form here: <a href="http://www.stonegroup.co.uk/support/raise-a-support-query.aspx">http://www.stonegroup.co.uk/support/raise-a-support-query.aspx</a>