

Using your Tablet Computer

Acer Aspire Switch 10

Acer Aspire Switch 10 - User Manual

Please click the link below for the User Manual for the Acer Aspire Switch 10.

[Acer Aspire Switch 10 User Manual](#)

Quick Access Reference

Please find below an index of useful content in the User Manual, with page numbers.

- Device Front View (With feature labels) - Page 8.
- Device Bottom View (With feature labels) - Page 9.
- Device Left/Right View (With feature labels) - Pages 9 and 10.
- LED Indicators - Page 10.
- Attaching and Detaching the Keyboard - Pages 13 and 14.
- Function Keys - Page 16.

Applies to:

- Acer Aspire Switch 10

Preventing Accidental Purchases on Android Based Devices

Problem

In-app purchases running up large bills on the Google play store. It is not always easy to spot an in-app purchase that charges you real money rather than in-game points or credits. If you are not careful, it is easy to spend hundreds or even thousands of pounds without realising it. These bills are your responsibility and not the responsibility of the laptop or tablet manufacturer.

Cause

Many games allow purchases of extra coins, credits, points, etc. It can be difficult to track exactly how much you have spent on these point or add-ons, or how many of these you have used when you play the game.

Instructions

Method 1: Change the Google play store password behaviour

1. Open up the google play store
2. Press the Menu button (≡)
3. Go to "Settings"
4. Press "Require authentication for purchases"
5. Choose "For all purchases"
6. Enter the password you use for your Google account

Note: It is a good idea to set the password on your Google account to be a different password to the one used to switch on or unlock your device.

Method 2: Remove your credit card information from Google Play

1. On a computer go to <http://wallet.google.com>
2. Log in with your Google Account
3. Click "Payment Methods" (this will be on the left)
4. Next to your credit/debit card click "remove"

Note: This will stop ALL google play purchases without you adding another card. However you can buy pre-paid cards for the Google play store from most supermarkets, Boots, Currys, PC World, the Post Office, Amazon, and Shell Petrol stations. These will allow you to continue to make purchases on/with your Google play account but will limit any financial damage caused by accidental purchases if they are the only payment method on your account.

Applies to:

- Tablets running the Android Operating System.

