

How to Clear the CMOS / BIOS Settings on an MSI H61M Motherboard


Clearing the CMOS

The method used to clear the CMOS settings on a Stone / MSI H61M motherboard is different to the method used on the Intel desktop board range. Use the instructions below to clear the settings.

MSI CMOS Clear Instructions

- Ensure the system is switched off
- Short the JBAT1 2-pin jumper block for 10 seconds either using a jumper, or a screwdriver
- Remove the short
- Turn the system back on

Note: Do not short the JBAT1 terminal while the system is powered on.



Use a suitable screwdriver or a 2-pin jumper to short JBAT1.



Applies to:

- Stone / MSI H61M desktop boards
 - BOAMOT-438 - SC Micro ATX H61M-P31 LGA 1155, DDR3 x2, DVI, VGA, PCIE x16, SATA II x4, DX10.1.
 - BOAMOT-443 - SC Micro ATX H61M-P31/W8 LGA 1155, DDR3 x2, DVI, VGA, PCIE x16, SATA II x4, DX10.1.

Article ID: 190

Last updated: 12 Oct, 2013

Updated by: Andrew Sharrad

Revision: 8

Stone Branded Products -> Desktop PCs and All-in-One (AIO) -> Frequently Asked Questions (FAQ) -> How to Clear the CMOS / BIOS Settings on an MSI H61M Motherboard

<https://kb.stonegroup.co.uk/index.php?View=entry&EntryID=190>